


# Frusheez Instructions

Thank you for renting a Frusheez Machine from Taylor Rental and Party Plus. Please follow the directions below for delicious frozen drinks for your event. If you have any questions or problems, don't hesitate to contact us at (518) 324-5100



## Before you begin:

- The unit must be plugged directly into the outlet with no extension cords (unless the cord is provided by Baystate).
- It must be out of the direct sun light.
- Mix flavors according to the directions on the bottle.

## Operating the Machine:

1. Switch the power and rotators to the ON position.
2. For frozen drinks, place the switches down in the snowflake ❄ position.
3. **DO NOT** add alcohol directly in the bowl (alcohol does not freeze).



## Tips:

- If you would like to add alcohol, you should pour the desired amount in your cup and then add the Frusheez mix.
- It may take up to 3 hours to freeze, depending on the temperature outside (for best results, you should start the machine before your guests arrive).
- When adding to the mix, use cold water.

**PLEASE CLEAN MACHINE BEFORE  
RETURNING USING INSTRUCTIONS PROVIDED**

